

Backup Parameters, Diagnostics and Programs – 0 Controls

Parameters:

1. Set up your computer to accept a file from the Fanuc control.
2. On the CRT select the DGNOS/PARAM key. Be sure the word PARAMETER is in the upper left-hand corner of the screen.
3. Select the EDIT key.
4. Select the EOB and OUTPUT keys at the same time. By selecting these two keys at the same time you will also save all the option parameters.
5. After selecting EOB and OUTPUT the word OUTPUT will flash at the bottom right-hand of the CRT screen.
6. When OUTPUT stops flashing the Fanuc has finished sending information.

Diagnostics:

1. Set up your computer to accept a file from the Fanuc control.
2. On the CRT select the DGNOS/PARAM key. Make sure the word DIAGNOSTICS is in the upper left-hand corner of the screen.
3. Select the EDIT key.
4. Select the OUTPUT key.
5. After selecting OUTPUT the word OUTPUT will flash at the bottom right-hand of the CRT screen.
6. When OUTPUT stops flashing the Fanuc has finished sending information.

Programs:

1. Set up your computer to accept a file from the Fanuc control.
2. On the CRT select the PROGRAM key.
3. Select the EDIT key.
4. In the soft key selection on the bottom of the screen select LIBRARY.
5. Type in the program file number, or 09999 to save all programs.
6. Select the OUTPUT key.
7. After selecting OUTPUT the word OUTPUT will flash at the bottom right-hand of the CRT screen.
8. When OUTPUT stops flashing the Fanuc has finished sending information.